

Operating Instructions



hawos Molere handmill

Operating Instructions

Congratulations on your new
hawos Molere hand-operated grain mill!

To ensure that you enjoy your new grain mill for a long time, we recommend that you read the following instructions carefully and keep them in a safe place.

Included in delivery are:

Hand mill, funnel, crank, 2 clamps and a collecting vessel.

Commissioning

1. Fix the grain mill in a suitable place using the two clamps supplied.
2. Put the crank on the axle and turn it in the direction of rotation to the right as far as it will go.
3. Put on the funnel.
4. Place the supplied collecting vessel under the grinder.
5. Determine the desired fineness using the two wing nuts.
6. Grind in the mill with approx. 30 g and discard the first grist.
7. Fill the grain into the hopper - and off you go!

We recommend:

Put different types of grain already mixed in the hopper and grind together.

What can be ground?

Basically, all dry grains can be ground to the desired fineness. Seeds containing oil can be ground mixed with wheat or spelt. The fineness of the flour can be adjusted by the wing nuts. The plate attached under the grinding stone can be bent slightly forward for better flour guidance.

Cleaning and care:

hawos hand mill Molere is made of solid beech wood that can occasionally be maintained with a commercial vegetable oil. The grinding stones made of corundum/ceramic can be brushed off with a brush.

The grinding shaft has two bearings and is permanently lubricated; it does not require any special care.

If you need to take a longer break from grinding, the hand mill can be dismantled for cleaning.

To do this, tighten the wing nuts so that the grinding stones block. Then turn the crank to the left, unscrew the wing nuts completely and pull off the front part.

Clean the stone surfaces with a hard brush.

Reassemble in reverse order
(do not forget the washers).

Clean the hand mill dry only!

Warranty 10 years from date of purchase

Although hawos products are manufactured to the highest standards, defects may occur. In the event of defects in material or workmanship, we will repair the mill free of charge within the warranty period. This does not include compensation for consequential damage, and does not apply in the event of loss, natural wear and tear, or damage resulting from improper use or lack of or improper care. The warranty applies in Germany to units intended for German delivery. Please note that you will need proof of purchase in order to claim under the guarantee. Of course, in the event of a defect, you retain your statutory warranty rights at all times, which you can assert against us independently of the warranty and which are not restricted by the warranty.

If a repair is necessary, please contact us by telephone at 06172-671749 or by e-mail at service@hawos.de.

hawos Kornmühlen GmbH
Massenheimer Weg 25
61352 Bad Homburg v.d.H.
Service telephone: 06172-671749
E-Mail: service@hawos.de
www.hawos.de



vital100.de
Bottenbacher Str. 13
57223 Kreuztal
Germany
Internet: www.vital100.de
E-Mail: info@vital100.de